



GROUP 4		STARTER MECHANISM
ITEM	* PART	DESCRIPTION
1	223447	STARTERSHAFT CPL-KICK
1	230913	STARTERSHAFT CPL-PEDAL
2	205702	THRUST WASHER
3	209048	CLAW COLLAR SPRING
4	a 209566	CLAW COLLAR-KICK
4	b 209047	CLAW COLLAR-PEDAL
5	217584	CHAIN SPROCKET-25 TOOTH
6	217582	CHAIN(32 ROLLERS)
7	223448	DISTANCE TUBE
8	032073	STARTERSHAFT RING
9	206391	SHIN 1.0MM
10	P 209087	SHIM 0.2MM
10	P 200175	SHIM 0.5MM
10	P 206391	SHIM 1.0 MM
11	223473	RETURN SPRING(FOR KICKSTART LEVER)
12	221406	KICKSTART LEVER HUB
13	221405	KICKSTART LEVER
14	a 201487	RUBBER SLEEVE
14	b 223602	RUBBER SLEEVE
15	260216	THRUST BOLT
16	260217	SPRING
17	202726	KICKSTART LEVER PIN
18	202723	DISTANCE BUSHING
19	a 202727	WASHER
19	b 200185	WASHER
20	031076	NUT
21	230292	PEDAL ARMS
22	222655	PEDALS (PAIR)
23	206714	PIN
24	200266	SEAL RING
25	209224	THRUST WASHER
26	209099	SPRING
27	209096	CUP
28	230915	DISTANCE TUBE