


GROUP 8 Exhaust, seat, luggage carrier



GROUP 8 Exhaust, seat, luggage carrier		
ITEM	PART	DESCRIPTION
1	236263	seat
2	031510	Washer 8
3	034027	Spring 2x12
4	236384	seat rubber
5	236396	luggage box
6	031933	Screw M6x10 (ISO 7380)
7	026591	Rubber bush
8	030049	nut M8-selflocked
10	232735	Tool tray (Revival)
11	026705	Screw
12	200516	Rubber bush
20	242170LAK	Luggage carrier
21	026696	Screw M6x50 (ISO 7380)
22	202723	Distance bush
23	026692	Screw M6x25 (ISO 7380)
24	030020	Cap nut M6
25	031926	Washer 8
26	223699	Rubber tube
27	232747	Distance tube
30	237014	exhaust A26-b
	242153S91	Exhaust guard
	026705	screwM6x10
	031509	Washer 6
33	205848	Distance ring
34	227149	Exhaust gasket
35	031845	Spring ring B6
36	030020	Cap nut M6
36	z 031075	Nut M6
37	026704	Screw M8x20 (ISO 7380)
38	031933	Washer 8
39	030041	Nut M8-selflocking